

**PRODUCTS AFFECTED / SERIAL NUMBERS AFFECTED:**

Canon imageRUNNER ADVANCE, imagePRESS, imageCLASS, varioPRINT 140/135 Series, and VarioPrint 6000 Series

**SUBJECT:**

Standard Cleaning Guidelines

**GENERAL:**

The following cleaning guidelines may be used to clean the Canon imageRUNNER ADVANCE, imagePRESS, imageCLASS, varioPRINT 140/135 Series, and VarioPrint 6000 Series Products.

**DETAILS:**

Please follow the procedure below for guidelines on how to clean the mentioned products.

- 1) All areas frequently accessed by customers (i.e. control panels, covers and jam locations) may be cleaned with Isopropyl Alcohol using the following precautions:
  - a. Make sure device is powered down and unplugged before cleaning. Wait until surfaces are dry before plugging in and powering device back on.
  - b. Don't spray any cleaning agent directly onto the machine, instead spray the cleaning agent onto a lint free cloth/rag and then wipe surfaces.
  - c. Cloths/Rags should be disposed of after one use.
  - d. Use only glass cleaner on the platen glass surface and wipe with a lint free cloth.

The effectiveness of microbe sterilization should be confirmed by an expert in this area.

**NOTE:**

Commercial wet wipes contain ingredients other than alcohol.  
Caution is required and recommendation is not possible.

**NOTE:**

This cleaning method does not guarantee effectiveness against any particular microbe.

**CAUTION:**

Alcohol is a flammable liquid and should never be used near fire or open flame.